



Established 1964

THF Australia Pty Ltd trading as
TUZA FLOATS

80-90 Vincent Avenue

Mulgoa NSW 2745

Phone: 1300 008 892

Email: sales@tuza.com.au

Web: www.tuza.com.au

ABN: 81 110 435 491

MAINTENANCE FOR A TUZA FLOAT

Tuza recommend a general service is taken place once every 12 -24 months depending how often the float is used.

Please note: WEAR & TEAR will occur to a steel horse float.

For example: Scratches to the paint work and steel from horse shoes and teeth, stone chips, normal tyre wear

Tuza recommend the following to maintain your horse float:

- **Horse float must be periodically washed with high quality car wash**
 - This will remove any foreign matter that may land on float while in transit i.e., Tar when passing road works.
 - Surface rust may appear on the exterior of the float if foreign matter sits on the float for an extended period.
- **Tuza recommend not to use Bore water to wash your float as it may contain a high amount of hydrogen sulphide that can cause corrosion.**
- **Horse float must be maintained with a lubricant spray, for example inox /Lanox spray or fish oil.**
 - This will keep pins and hinges rust free and operating correctly.
- **Cut and polish should be used on Scratches & stone chips to prevent surface rust.**
- **Pop up vents need to be firmly closed to stop water leakage. Firmly closing engages the foam seal.**
- **When hosing out interior of horse float**
 - Do not hose directly at the roof line
 - Do not hose directly at side pads on the horse float
 - It is recommended to wipe these areas down to prevent water becoming trapped.